



# Installation Instructions

Save labor, time and money with easy installation and removal; more efficient and cost effective than manually removing overspray deposits and residues from floor surfaces.

Flame retardant paper diminishes potential fire hazards and help you meet USA OSHA and NFPA safety standards for combustible floor surfaces, materials and deposits. [OSHA 1910.107(b)(3), NFPA 33, 8.2].

Vivid bright white paper illuminates booth visibility, reducing rejects by minimizing shadows.

Stop scraping and start rolling!

## Materials Required:

1. Tack cloth
2. Scissors, knife or box cutter
3. Industrial tape

## Installation:

1. For best adhesion of tape, ensure floor is clean and dust free. Use tack cloth on areas where tape will adhere.
2. Start in a corner. Tape down the end of the roll.
3. Unroll paper to desired length and cut.
4. Tape down loose end.
5. Repeat process, overlapping seams, until floor is covered.
6. Tape down seams if desired.

